



KickPlate Storage & Handling, Preparation, Installation, & Cleaning Procedures

STORAGE & HANDLING:

1. Within 72 hours after delivery, inspect the product for any defects. If the item has a defect, please notify TheKickPlateStore by providing an order number, quantity damaged, and photos of the damaged product. If the package is damaged at the time of delivery, review our [Shipping & Returns](#) policy.
2. Store the finished kick plates in a clean and dry area. The material must reach 65° F. min to 75° F. max 24 hours prior to installation.

INSTALLATION PREPARATION:

1. Ensure that the wall surface is dry, clean, and free of any dust, dirt, loose paint, wax, oil, or grease by wiping with a solvent.

INSTALLATION USING ADHESIVE:

1. Apply a bead of heavy-duty construction adhesive (i.e.: Liquid Nails) using a zig-zag pattern over the back of the kickplate. The bead width should be approximately 1/4in thick.
2. Position the plate on the door/wall and apply pressure until a tight fit is achieved. Ensure the plate is level and at the correct height prior to applying pressure.
3. Once the plate has been installed, remove the protective covering. Please note the brushed aluminum plates will not have a protective covering.

INSTALLATION USING SCREWS:

1. Position the plate on the door/wall at the desired location and mark the hole locations on the wall. Ensure the plate is level and at the correct height prior to applying pressure.
2. Drill screw holes at each mark made on the wall.
3. Clean the wall to remove any dust or plaster.
4. Position the plate back on the door/wall at the desired location and attach the wall using the factory-supplied screws.
5. Once the plate has been installed, remove the protective covering. Please note the brushed aluminum plates will not have a protective covering.



CLEANING INSTRUCTIONS:

- For basic cleaning, including fingerprints, use warm water with a mild soap or an organic solvent (e.g., Acetone, alcohol, methylated spirits), sponge rinse with clean water, and wipe dry following the polish lines.
- For more difficult stains and grease use an organic solvent, mild cleaning, or specialty stainless steel cleaners. Use a sponge, rag, or soft fiber brush to clean, rinse well with a sponge and clean water and wipe dry following the polish lines. Always follow the instructions on all cleaning products prior to use.
- We do not recommend the use of any cleaners, such as Ajax or Comet, containing abrasive components that may scratch and/or leave a powdery residue.

CAUTION:

- DO NOT walk on the kickplates.
- DO NOT store anything on top of the kickplates.